
## 300mm JOIST - 75mm TOPPING - 930mm SPACING



DEFLECTIONS						
	Dead Load	Precamber	Drying Shrinkage	Superimposed Dead	Creep	Total
	Deflection	in joist	Deflection	Load Deflection	Deflection	Deflection
	$\Delta_{Gc}$	$\Delta_{ m pc}$	$\Delta_{shr}$	$\Delta_{Gs}$	$\Delta_{\operatorname{Cr}}$	
span	mm	mm	mm	mm	mm	mm
1m	0.01	0	0.06	0.00	1.00	1.07
2m	0.10	0	0.24	0.01	1.00	1.35
3m	0.50	-0.5	0.54	0.04	1.00	1.58
4m	1.57	-2	0.96	0.14	1.00	1.67
5m	3.83	-5	1.50	0.35	1.00	1.68
6m	7.94	-10	2.17	0.72	1.00	1.82
7m	14.71	-14	2.95	1.33	1.00	5.99
8m	25.10	-16	3.85	2.27	1.00	16.21
9m	40.20	-18	4.87	3.63	1.00	31.71

L/360 deflection criteria

requires specific design

The above chart and table must be read in conjunction with notes on page 10 of the Speedfloor Design Manual and have been designed in accordance with the relevant standards and codes as specified on page 11.



long term live loads